



Tile Trim Solutions

Floor Transitions • Walls & Counters • Protects Tile Edges

Installation for all Profiles Except T-Shape

1. Choose shape and profile according to tile thickness.
2. Apply thin set mortar according to manufacturer's directions to the area where profile is to be placed, using the appropriate size U notch trowel.
 - 2a. For edging and outside wall corners using L-Shape or R-Round Bullnose, finish tiling one wall first, then trowel thin set mortar over corner areas of second wall.
 - 2b. For the U-Shape Reducer, fill the hollow space beneath the sloped section of profile with thin set mortar before setting the trim.
3. Press the perforated anchoring leg of the profile into the mortar until mortar fills the circle cutouts. Then align trim with tile edge making sure the tile is flush against lower edge of trim face to ensure a uniform grout joint space between trim and tile.
4. Trowel additional thin set mortar evenly over the perforated anchoring leg completely covering the circle cutouts to ensure full coverage and support of the tile edges. The anchor leg should be partially buried in the sealant.
5. Ensure the tile is flush with top of profile or slightly lower. The profile should not be higher than the tiled surface, but rather up to approx. 1/32" (1 mm) lower.
6. After the tiles and profile have set, fill the grout joint completely with grout.
7. Gently wipe off any excess grout or thin set mortar immediately.

TrimMaster™
Featuring Straight Edge Grout Line

Exposed edges of ceramic and stone tiles can chip or crack if left unprotected. Professional profile trims are designed for floors, walls and countertops. They protect thresholds, floor transitions and other edges while providing an attractive and decorative accent to any project. The trims feature patent pending protected designs including new "Straight Edge Grout Line" for a professional finished look.



Installation for T-Shape Profile

1. Select shape according to width of the gap or joint to be covered.
2. Make sure the gap is clean and free from obstruction that would hinder the shape from setting level on the tile or flooring material.
3. Caulk the joint with a silicone or elastomeric caulk being careful not to overfill the joint.
4. Insert the anchoring leg into the gap so the edges of the profile rest on the edges of the flooring material and covering the gap. The anchor leg should be partially buried in the sealant.
5. Gently position the profile so it is straight.
6. Immediately remove any excess sealant and let sealant cure according to manufacturer's directions.



Maintenance and Cleaning Guide

Trim Master products are designed for years of maintenance free service and do not require any special maintenance. Clean them regularly using common household cleaning agents. Do not use cleaning agents with hydrochloric and hydrofluoric acid. Abrasive cleaners should not be used on anodized aluminum as they may scratch the surface. Remove any grout, mortar or thin set from the surface immediately after installation.

**10 Year
Residential
Warranty**